

# PRODUCT INSTRUCTIONS


## ➤ Product Introduction

This Gharial tag is mainly used in the field of anti-theft, specially designed for different thickness pouches, such as dishwasher ball packs and laundry tablets pouches.


Dimension: 67mmx42mmx34mm

Weight: 47g

### Gharial Tag




### Detacher




## ➤ Locking

1. Place the pack in the rack of gharial tag. Then the tag will flash and make a beeping.





2. Try to put the pack in the innermost rack, then rotate the cover of the tag to lock it.



## ➤ Unlocking

Align the unlocking area of the detacher with the tag, gently press the upper part of the tag, and the cover will pop out. Then, take out the goods.



## ➤ CAUTIONS

1. Place the goods on the tag and lock it.

After hearing a "beeping", if you remove the tag within 15 seconds, no alarm will be triggered.  
But if you remove the tag after 15 seconds, unexpected alarm will go off. Put the tag on a magnetic detacher to stop the alarming

2. Unexpected alarm will go off too if you first remove both the tag and the goods from the detacher and then remove the goods when unlocking. Put the tag on a magnetic detacher to stop the alarming.